



VisionLabs
MACHINES CAN SEE

VisionLabs FaceStream

Upgrade manual from v.5.1.9 to v.5.1.10

v.5.1.10

Contents

Glossary	4
1 Introduction	5
2 System requirements	6
2.1 Minimum requirements	6
3 Software requirements	7
General information	8
4 Before upgrading	9
4.1 Create backup	9
4.2 Create copy of LUNA Configurator settings	9
4.3 Prepare dump file for migrations	9
4.4 Delete symbolic link	9
4.5 Unpacking	10
4.6 Symbolic link creation	10
4.7 Move data	11
4.7.1 Copy PostgreSQL data	11
4.7.2 Copy InfluxDB Data	11
4.8 Remove old containers	11
4.9 Enable logging to file for FaceStream	12
4.10 License key activation	13
4.10.1 License key activation when LP is launched	13
4.10.2 License key activation when LP is not launched	13
4.10.2.1 Install HASP utility	14
4.10.2.2 Configure HASP utility	15
4.10.2.3 Add LP vendor library	15
4.10.2.4 Create fingerprint for LUNA PLATFORM	15
4.10.2.5 Add a license file manually using user interface	16
4.10.2.6 Specify license server address	16
4.10.2.7 Delete LP hasp utility	17
4.11 Upgrade and launch LP services	17
4.11.1 InfluxDB OSS 2 container launching	17
4.11.2 PostgreSQL container launching	18
4.11.3 LUNA Configurator database migration	19
4.11.3.1 LUNA Configurator DB initialization	19
4.11.4 LUNA Configurator container launching	20

4.11.5	LUNA Licenses container launching	20
4.11.5.1	Specifying LUNA Licenses server address	21
5	Upgrade FaceStream	22
5.1	Settings migration in LUNA Configurator	22
5.2	LUNA Streams database migration	22
5.3	Command for launching LUNA Streams container	22
5.4	Commands for launching FaceStream container	23
5.4.1	Command for launching container using CPU	23
5.4.2	Command for launching container using GPU	23
5.4.3	Launching keys	24
5.4.4	Description of container launch parameters	26
6	Docker commands	27
6.1	Show containers	27
6.2	Copy files to container	27
6.3	Enter container	27
6.4	Images names	27
6.5	Show container logs	27
6.6	Delete image	28
6.7	Stop container	28
6.8	Delete container	28

Glossary

Term	Meaning
Aspect angle	Head rotation degree (in degrees) on each of the three axes (up/down tilt relative to the horizontal axis; left/right tilt, relative to the vertical axis; a rotation about the vertical axis).
Bestshot	Best shot is selected from all frames of the track. The main conditions for best shot selection are appropriate quality and the presence of a face with best aspect angle. Such conditions are set through FaceStream configuration.
Detection	FaceStream entity that contains the coordinates of face or body and the estimated value of the object that determines the bestshot.
Descriptor	A set of unique features received from the warp. A descriptor requires much less storage memory in comparison with the sample and is used for comparison of faces.
Event	LUNA PLATFORM entity, which contains information (city, user data, track id, etc.) about one face and/or body. This information is transferred to the LUNA PLATFORM by the FaceStream application. For a complete list of the transferred information, see the OpenAPI LUNA PLATFORM documentation.
Normalized image, warp	Images containing a face or body and corresponding to VisionLabs standard. Used when working with LUNA PLATFORM.
Portrait	Image of face or body that has been transformed to a specific format. The portrait has two types - “warp” (the image is transformed into warp format), “gost” (detection is cut out from the source frame, considering indentation).
Track	Information about object’s position (face of a person) in a sequence of frames. If the object leaves the frame zone, the track doesn’t discontinue right away. For some time, the system expects the object to return and if it does, the track continues.
Tracking	Object (face) tracking function in the frame sequence.

1 Introduction

This document provides an example of the steps required to upgrade to a new build of FaceStream. The FaceStream build includes FaceStream itself and the LUNA Streams service. Because FaceStream requires the InfluxDB, PostgreSQL, LUNA Configurator, and LUNA Licenses services to run, this manual provides commands to save data from these services.

This manual is intended with an assumption that:

- you already have a previous minor version of FaceStream distribution installed and the required environment is up and running at your server(s).
- FaceStream is installed according to FaceStream installation manual, and the default paths are used. Otherwise, you should consider your manual changes during the update.

This document includes an example of FaceStream deployment. It implements LUNA PLATFORM minimum power operating for demonstration purposes and cannot be used for the production system.

All the provided commands should be executed using the Bash shell (when you launch commands directly on the server) or Putty (when you remotely connect to the server). The provided commands were tested with these utilities only. The use of other shells or emulators may lead to errors when executing commands.

2 System requirements

2.1 Minimum requirements

The following minimum requirements are given per FaceStream instance.

For the application to work correctly, the hardware must meet the following minimum requirements:

- 2 GHz or faster processor;
- 4 Gb RAM or higher;
- 10 Gb available hard disk space.
- Access to the Internet (for containers and additional software download).

Hardware requirements can be affected by several factors:

- Number of video streams;
- Frame frequency and resolution of video streams;
- FaceStream settings. The default settings are the most versatile. Depending on the operating conditions of the application, using their values can affect the quality, or performance.

Hardware should be selected based on the above factors.

FaceStream can also work in the computation speedup mode due to:

Video card resources usage

GPU calculations are supported for FaceDetV3 only. See “defaultDetectorType” parameter in the FaceEngine configuration (“faceengine.conf”).

A minimum of 6GB or dedicated video RAM is required. 8 GB or more VRAM recommended.

Pascal, Volta, Turing architectures are supported.

Compute Capability 6.1 or higher and CUDA 11.4 are required.

The recommended NVIDIA driver is 470.103.01.

Now only one video card is supported per FaceStream instance.

AVX2 instructions usage

CPU with AVX2 support is required.

The system automatically detects available instructions and runs best performance.

3 Software requirements

FaceStream and LUNA Streams containers launch were tested on the following operating systems:

- CentOS Linux release 7.8.2003 (Core)

The following OS is used inside the FaceStream container:

- CentOS Linux release 8.3.2011

Docker should be installed for containers launch. To upload settings to the LUNA Configurator service, Python version 2.x or 3.x is required.

General information

It is recommended to read and understand this document. It will help you to find out what components FaceStream consists of and what tasks they solve.

Deploy should be performed in the order specified in the document.

All the procedures in the following manual are described for CentOS. If it is required to deploy dockers on any other OS, please refer to the Docker Compose documentation for information:

<https://docs.docker.com/compose/install/>

FaceStream requires LUNA PLATFORM components, additional databases, and the LUNA Streams service. Basic information about this software is contained in this document.

LUNA Streams is not a component of the LUNA PLATFORM.

The following LUNA PLATFORM components are used by default with FaceStream.

- LUNA Licenses is used to license the LUNA Streams service.
- LUNA Configurator is used for quick access to the basic FaceStream settings and LUNA PLATFORM service settings.
- PostgreSQL is used as the default database for the LUNA Streams service. It is also possible to use an Oracle database instead of PostgreSQL.
- InfluxDB is used for monitoring. If necessary, monitoring can be disabled.

The following database versions are recommended for use with LUNA Streams:

- PostgreSQL: 12
- Oracle: 11.2

Installation and configuration of Oracle is not described in this manual. Further in the document, examples of launching using PostgreSQL will be given.

Balancers and other software can be used when scaling the system to provide fail-safety. Their configuration is not described in this document.

4 Before upgrading

Before upgrading FaceStream, you need to complete a number of additional steps.

4.1 Create backup

Create backups for the LUNA Streams database before performing the migration procedures. You can restore your data if any problems occur during the migration.

Backups creation for database is not described in this document.

4.2 Create copy of LUNA Configurator settings

To keep the Configurator settings used in the previous version of FaceStream, back up the configuration file `/var/lib/fs/fs-current/extras/conf/configurator_configs/luna_configurator_postgres.conf` in a separate directory on the server.

```
cp /var/lib/fs/fs-current/extras/conf/configurator_configs/  
luna_configurator_postgres.conf /var/lib/fs/  
BACKUP_luna_configurator_postgres.conf
```

4.3 Prepare dump file for migrations

If the previous version of FaceStream was used with non-default settings for other services, back up the services settings file to a separate directory on the server outside of the Configurator service container.

To create a dump-file, use the following options (may be executed from anywhere on your server):

```
wget -O /var/lib/fs/settings_dump_backup.json 127.0.0.1:5070/1/dump
```

or

```
curl 127.0.0.1:5070/1/dump > /var/lib/fs/settings_dump_backup.json
```

It is not required to use this backup during the upgrade. It should be used only in case when something went wrong.

4.4 Delete symbolic link

Delete the symbolic link to the previous minor version directory using the following command:

```
rm -f /var/lib/fs/fs-current
```

4.5 Unpacking

It is recommended to move the archive to a pre-created directory for FaceStream and unpack the archive there.

The following commands should be performed under the root user.

Create a directory for FaceStream.

```
mkdir -p /var/lib/fs
```

Move the archive to the created directory. It is considered that the archive is saved to the “/root” directory.

```
mv /root/facestream_docker_v.5.1.10.zip /var/lib/fs/
```

Go to the directory.

```
cd /var/lib/fs/
```

Install the unzip utility if it is not installed.

```
yum install unzip
```

Unpack the archive.

```
unzip facestream_docker_v.5.1.10.zip
```

You will need to configure FaceStream before launching it.

The unpacked archive includes all the configuration files required for the FaceStream launch. The configuration parameters description is given further in this document.

4.6 Symbolic link creation

Create a symbolic link. The link indicates that the current version of the distribution file is used to run the software package.

```
ln -s facestream_docker_v.5.1.10 fs-current
```

4.7 Move data

Move the data for your databases to the directory with new distribution.

It is considered, that you use the default paths for storing databases and buckets.

The example is provided for updating from version v.5.1.9. You should perform these actions for the FaceStream build installed on your server. Change v.5.1.9 in commands below to your currently installed build.

You should copy the data folder of your database from “facestream_docker_v.5.1.9” directory to the current root. Thus you can use your data in the new FaceStream build.

4.7.1 Copy PostgreSQL data

The following step is required if you are using PostgreSQL in Docker container.

Copy the “data” folder:

```
cp -r /var/lib/fs/facestream_docker_v.5.1.9/example-docker/postgresql /var/lib/fs/fs-current/example-docker/
```

4.7.2 Copy InfluxDB Data

The following step is required if you are using InfluxDB in Docker container.

Copy the “influx” folder with all its buckets:

```
cp -r /var/lib/fs/facestream_docker_v.5.1.9/example-docker/influx /var/lib/fs/fs-current/example-docker/
```

4.8 Remove old containers

Before launching the containers of the current minor version, stop all FaceStream related containers of the previous minor version and third-party software containers.

PostgreSQL and InfluxDB containers can also be removed as their versions can be updated in new build.

PostgreSQL and InfluxDB require restarting even if their containers were not changed. This is related to the transfer of their data folders. See [“Move data”](#).

To delete a container use the next command:

```
docker container rm -f [container_name]
```

where [container_name] is the service docker container name or ID.

For example, to remove the FaceStream, LUNA Streams, LUNA Configurator, and LUNA Licenses containers, use the following command:

```
docker container rm -f facestream luna-streams luna-configurator luna-licenses
```

To see the containers names or IDs, use the following command:

```
docker ps -a
```

It is also recommended to delete old images of the containers to free space. You can use the following command to delete all unused images.

If there is enough space on the server it is recommended to perform this action only after new version of FaceStream is successfully launched.

The command deletes all the unused images, not only the images related to FaceStream.

```
docker image prune -a -f
```

4.9 Enable logging to file for FaceStream

Note. Use the steps below only if you need to save logs to a file. By default, logs are output to the console. To view the logs from the console, use the `docker logs <container_name>` command.

If necessary, you can write the FaceStream logs in separate files. To do this, you should first create directory to save logs.

The log directory is created with the following command:

```
mkdir -p /var/lib/fs/fs-current/logs/
```

The directory for storing logs can be changed if necessary.

To enable logging, you should enable logging to a file in the FaceStream settings. To do this, you need to set the value of the “mode” parameter to “l2f” (output logs only to file) or “l2b” (output logs and file to the console).

To enable logging, you need to run the following command when starting the container:

```
-v /var/lib/fs/fs-current/logs/:/srv/logs/ \
```

Data from the specified folder is added to the Docker container when it is launched. All the data from the specified Docker container folder is saved to this directory.

To write LUNA service logs, follow the same steps.

By default, only system warnings are displayed in the FaceStream logs. By setting the “severity” parameter, you can enable error output (see the parameter description in the administrator manual).

4.10 License key activation

In most cases, there is no need to get a separate license when upgrading minor versions. The only time this may be needed is when updating a license. For example, the LP library has changed.

If the LUNA PLATFORM 5 license has not changed, skip this step.

4.10.1 License key activation when LP is launched

If the LUNA PLATFORM services are already launched and the license with a parameter that determines the streams number for LUNA Streams operation is already activated, then you need to make sure that the current LUNA PLATFORM key contains this parameter. The information can be provided by VisionLabs specialists.

If this parameter is not contained in the key, then you need to request a new key and contact VisionLabs specialists for advice on updating the license key.

If LUNA Streams is launched on a server other than the one on which LUNA Licenses is launched, then you should perform the steps described in the section [“Specifying LUNA Licenses server address”](#).

4.10.2 License key activation when LP is not launched

If the LUNA PLATFORM services are not launched or the launch is performed using Docker Compose, then it is assumed that the license has not yet been activated and it is necessary to request a new LUNA PLATFORM 5 license with a parameter determining the streams number for LUNA Streams operation, and go through the full LUNA PLATFORM 5 licensing process.

The HASP service is used for LUNA PLATFORM licensing. Without a license, you will be unable to run and use LUNA services and create streams for FaceStream.

There is a HASP key that enables you to use LUNA PLATFORM and create streams in FaceStream. It uses the haspvlib_x86_64_30147.so vendor library.

You can find the vendor libraries in the “/var/hasplm/” directory.

License keys are provided by VisionLabs separately upon request. The utilized Liveness version is specified in the LUNA PLATFORM license key.

A network license is required to use LUNA PLATFORM and FaceStream in Docker containers.

The license key is created using the fingerprint. The fingerprint is created based on the information about hardware characteristics of the server. Therefore, the received license key will only work on the same server where the fingerprint was obtained. There is a possibility that a new license key will be required when you perform any changes on the license server.

Follow these steps:

- Install HASP utility on your server. HASP utility is usually installed on a separate server;
- Start the HASP utility;
- Create the fingerprint of your server and send it to VisionLabs;
- Activate your key, received from VisionLabs;
- Specify your HASP server address in a special file.

The Sentinel Keys tab of the user interface (<server_host_address>:1947) shows activated keys.

LP uses HASP utility of a certain version. If an older version of HASP utility is installed, it is required to delete it before installation of a new version. See [“Delete LP hasp utility”](#).

4.10.2.1 Install HASP utility

Go to the HASP directory.

```
cd /var/lib/fs/fs-current/extras/hasp/
```

Install HASP utility on you server.

```
yum -y install /var/lib/fs/fs-current/extras/hasp/aksusbd-*.rpm
```

Launch HASP utility.

```
systemctl daemon-reload
```

```
systemctl start aksusbd
```

```
systemctl enable aksusbd
```

```
systemctl status aksusbd
```

4.10.2.2 Configure HASP utility

You can configure the HASP utility using the “/etc/hasplm/hasplm.ini” file.

Note! You do not need to perform this action if you already have the configured INI file for the HASP utility.

Delete the old file if necessary.

```
rm -rf /etc/hasplm/hasplm.ini
```

Copy the INI file with configurations. Its parameters are not described in this document.

```
cp /var/lib/fs/fs-current/extras/hasp/hasplm.ini /etc/hasplm/
```

4.10.2.3 Add LP vendor library

Copy LP vendor library (x32 and x64). This library is required for using LP license key.

```
cp /var/lib/fs/fs-current/extras/hasp/haspvlib_30147.so /var/hasplm/
```

```
cp /var/lib/fs/fs-current/extras/hasp/haspvlib_x86_64_30147.so /var/hasplm/
```

Remove old version LP libraries if present:

```
rm -f /var/hasplm/haspvlib_x86_64_111186.so /var/hasplm/haspvlib_111186.so
```

Restart the utility

```
systemctl restart aksusbd
```

4.10.2.4 Create fingerprint for LUNA PLATFORM

Go to the HASP directory.

```
cd /var/lib/fs/fs-current/extras/hasp/licenseassist
```

Add permissions to the script.

Run the script.

```
./LicenseAssist fingerprint > fingerprint_30147.c2v
```

The fingerprint is saved to file “fingerprint_30147.c2v”.

Send the file to VisionLabs. Your license key will be created using this fingerprint.

4.10.2.5 Add a license file manually using user interface

- Go to: <host_address>:1947 (if access is denied check your Firewall/ SELinux settings (the procedure is not described in this document));
- Select the **Update/Attach** at the left pane;
- Press the “Select File...” button and select a license file(s) in the appeared window;
- Press the “Apply File” button.




Figure 1: License file is added manually

4.10.2.6 Specify license server address

Specify your license service IP address in the configuration file in the following directory:


```
/var/lib/fs/fs-current/extras/hasp_redirect/
```

Change address to the HASP server in the following documents:

```
vi /var/lib/fs/fs-current/extras/hasp_redirect/hasp_30147.ini
```

Change the server address in “hasp_30147.ini” file.

```
serveraddr = <HASP_server_address>
```

The “hasp_30147.ini” file is used by the Licenses service upon its container launch. It is required to restart the launched container when the server is changed.

HASP_server_address - the IP address of the server with your HASP key. You must use an IP address, not a server name.

4.10.2.7 Delete LP hasp utility

This action is performed to delete HASP utility.

Stop and disable the utility.

```
systemctl stop aksusbd
```

```
systemctl disable aksusbd
```

```
systemctl daemon-reload
```

```
yum -y remove aksusbd haspd
```

4.11 Upgrade and launch LP services

4.11.1 InfluxDB OSS 2 container launching

InfluxDB 2.0.8-alpine is required for LP monitoring purpose (for more information, see the “Monitoring” section in the LUNA PLATFORM administrator manual).

Note! If you already have InfluxDB 2.0.8-alpine installed, skip this step.

Use the `docker run` command with these parameters:

```

docker run \
-e DOCKER_INFLUXDB_INIT_MODE=setup \
-e DOCKER_INFLUXDB_INIT_BUCKET=luna_monitoring \
-e DOCKER_INFLUXDB_INIT_USERNAME=luna \
-e DOCKER_INFLUXDB_INIT_PASSWORD=password \
-e DOCKER_INFLUXDB_INIT_ORG=luna \
-e DOCKER_INFLUXDB_INIT_ADMIN_TOKEN=
    kofqt4Pfqn6o0RBtMDQqVoJLgHoxxDUmmhiAZ7JS6VmEnrqZXQhxDhad8AX9tmiJH6CjM7Y1U8p5eSEocG
    == \
-v /etc/localtime:/etc/localtime:ro \
-v /var/lib/fs/fs-current/example-docker/influx:/var/lib/influxdb2 \
--restart=always \
--detach=true \
--network=host \
--name influxdb \
dockerhub.visionlabs.ru/luna/influxdb:2.0.8-alpine

```

4.11.2 PostgreSQL container launching

If you already have PostgreSQL installed, skip this step.

Use the following command to launch PostgreSQL.

```

docker run \
--env=POSTGRES_USER=luna \
--env=POSTGRES_PASSWORD=luna \
--shm-size=1g \
-v /var/lib/fs/fs-current/example-docker/postgresql/data:/var/lib/
    postgresql/data/ \
-v /var/lib/fs/fs-current/example-docker/postgresql/entrypoint-initdb.d:/
    docker-entrypoint-initdb.d/ \
-v /etc/localtime:/etc/localtime:ro \
--name=postgres \
--restart=always \
--detach=true \
--network=host \
dockerhub.visionlabs.ru/luna/postgis-vmatch:12

```

-v /var/lib/luna/current/example-docker/postgresql/data:/var/lib/postgresql/data/ - the volume command enables you to mount the “data” folder to the PostgreSQL container. The folder on the server and the folder in the container will be synchronized. The PostgreSQL data from the container will be saved to this directory.

--network=host - if you need to change the port for PostgreSQL, you should change this string to -p 5440:5432. Where the first port 5440 is the local port and 5432 is the port used inside the container.

4.11.3 LUNA Configurator database migration

The following instruction for migrating the LUNA Configurator service database assumes that the configuration migration revision is already installed in the database. The revision is set using the --profile platform head script. This script is included in the FaceStream installation manual. If the installation was performed according to the manual, no additional steps are required. Settings will be migrated automatically.

If there is no revision, you should re-create the database structure and run the --profile platform head script. See the FaceStream installation manual, section “LUNA Configurator DB initialization”. Then you need to set all the necessary settings manually.

4.11.3.1 LUNA Configurator DB initialization

When upgrading the LUNA Configurator database with existing settings, you should perform database structure migration and saved settings migration.

Your current database should already have settings migration revision.

Use the docker run command with these parameters to create the LUNA Configurator database tables.

```
docker run \
-v /etc/localtime:/etc/localtime:ro \
-v /var/lib/fs/fs-current/extras/conf/configurator_configs/
  luna_configurator_postgres.conf:/srv/luna_configurator/configs/config.
  conf \
--network=host \
--rm \
--entrypoint bash \
dockerhub.visionlabs.ru/luna/luna-configurator:v.2.0.62 \
-c "alembic upgrade head; cd /srv/luna_configurator/configs/configs/;
  python3 -m configs.migrate --config /srv/luna_configurator/configs/config
  .conf --profile platform head;"
```

alembic upgrade head; - upgrades already existing database structure.

python3 -m configs.migrate --profile platform head; - performs settings migrations in LUNA Configurator DB and sets revision for migration. The revision will be required during the upgrade to the new LUNA Configurator build.

4.11.4 LUNA Configurator container launching

Use the `docker run` command with these parameters to launch Configurator:

```
docker run \
--env=PORT=5070 \
--env=WORKER_COUNT=1 \
--env=RELOAD_CONFIG=1 \
--env=RELOAD_CONFIG_INTERVAL=10 \
-v /etc/localtime:/etc/localtime:ro \
-v /var/lib/fs/BACKUP_luna_configurator_postgres.conf:/srv/luna_configurator
  /configs/config.conf \
--name=luna-configurator \
--restart=always \
--detach=true \
--network=host \
dockerhub.visionlabs.ru/luna/luna-configurator:v.2.0.62
```

4.11.5 LUNA Licenses container launching

Make sure that you have specified the license server address in the “hasp_30147.ini” file. See section [“Specify license server address”](#).

Add the access right for the “luna” user to the “hasp_redirect” directory.

```
chown -R 1001:0 /var/lib/fs/fs-current/extras/hasp_redirect/
```

Use the following command to launch the service:

```
docker run \
--env=CONFIGURATOR_HOST=127.0.0.1 \
--env=CONFIGURATOR_PORT=5070 \
--env=PORT=5120 \
--env=WORKER_COUNT=1 \
--env=RELOAD_CONFIG=1 \
--env=RELOAD_CONFIG_INTERVAL=10 \
-v /etc/localtime:/etc/localtime:ro \
-v /var/lib/fs/fs-current/extras/hasp_redirect/hasp_30147.ini:/home/luna/.
  hasplm/hasp_30147.ini \
--name=luna-licenses \
--restart=always \
--detach=true \
--network=host \
```

```
dockerhub.visionlabs.ru/luna/luna-licenses:v.0.3.69
```

4.11.5.1 Specifying LUNA Licenses server address

Note. Perform the following actions only if you launch LUNA Streams not on a server with LUNA Licenses. Otherwise, you can skip this step.

Go to the user interface of the LUNA Configurator service and select “luna-streams” from the “Service name” drop-down list.

In the “LUNA_LICENSES_ADDRESS” section, specify the address of the server where the LUNA Licenses service is launched.

5 Upgrade FaceStream

Before launching FaceStream, the steps described in the “[Before upgrade](#)” section must be completed.

5.1 Settings migration in LUNA Configurator

LUNA Streams settings are automatically migrated when the LUNA Configurator service settings are migrated.

If the LUNA Configurator service was launched using the FaceStream documentation, the settings are migrated in the “[LUNA Configurator database migration](#)” step.

If the LUNA Configurator service was launched using the LUNA PLATFORM documentation, then you should use the same step in the LUNA PLATFORM documentation.

FaceStream settings do not require migration in the current release.

5.2 LUNA Streams database migration

Run migration script to update the LUNA Streams database structure.

It is recommended that you back up your database before taking any changes.

```
docker run \  
-v /etc/localtime:/etc/localtime:ro \  
--rm \  
--network=host \  
dockerhub.visionlabs.ru/luna/luna-streams:v.0.5.2 \  
alembic -x luna-config=http://127.0.0.1:5070/1 upgrade head
```

5.3 Command for launching LUNA Streams container

The container is launched with the following command:

```
docker run \  
--env=CONFIGURATOR_HOST=127.0.0.1 \  
--env=CONFIGURATOR_PORT=5070 \  
--env=PORT=5160 \  
--env=WORKER_COUNT=1 \  
--env=RELOAD_CONFIG=1 \  
--env=RELOAD_CONFIG_INTERVAL=10 \  
-v /etc/localtime:/etc/localtime:ro \  
--name=luna-streams \  

```

```
--restart=always \  
--detach=true \  
--network=host \  
dockerhub.visionlabs.ru/luna/luna-streams:v.0.5.2
```

5.4 Commands for launching FaceStream container

5.4.1 Command for launching container using CPU

The container is launched as follows:

```
docker run \  
--env=CONFIGURATOR_HOST=127.0.0.1 \  
--env=CONFIGURATOR_PORT=5070 \  
-v /var/lib/fs/fs-current/extras/conf/configs/faceengine.conf:/srv/  
    facestream/data/faceengine.conf \  
-v /etc/localtime:/etc/localtime:ro \  
--env=PORT=34569 \  
--detach=true \  
--restart=always \  
--name=facestream \  
--network=host \  
dockerhub.visionlabs.ru/luna/facestream:v.5.1.10
```

For a description of the remaining parameters and launching keys, see the relevant sections below.

The list of streams is available at <http://127.0.0.1:34569/api/1/streams/>. Viewing the stream in the browser is available at http://127.0.0.1:34569/api/1/streams/preview/<stream_id>.

5.4.2 Command for launching container using GPU

Note. Use this command only if you are going to use FaceStream with GPU.

Before launching FaceStream in GPU mode, additional dependencies should be installed (see “[GPU dependencies installation](#)” section).

Before starting the FaceStream container with GPU, it is required to **enable GPU** for calculations in the FaceStream settings using the “enable_gpu_processing” parameter (see the “FaceStream configuration” section in the administrator manual).

```
docker run \  
--env=CONFIGURATOR_HOST=127.0.0.1 \  

```

```

--env=CONFIGURATOR_PORT=5070 \
-v /var/lib/fs/fs-current/extras/conf/configs/faceengine.conf:/srv/
  facestream/data/faceengine.conf \
-v /etc/localtime:/etc/localtime:ro \
--env=PORT=34569 \
--gpu device=0 \
--detach=true \
--restart=always \
--name=facestream \
--network=host \
dockerhub.visionlabs.ru/luna/facestream:v.5.1.10

```

--gpu device=0 - the parameter specifies the used GPU device and enables GPU utilization. A single GPU can be utilized per FaceStream instance. Multiple GPU utilization per instance is not available.

For a description of the remaining parameters and launching keys, see the relevant sections below.

The list of streams is available at <http://127.0.0.1:34569/api/1/streams/>. Viewing the stream in the browser is available at http://127.0.0.1:34569/api/1/streams/preview/<stream_id>.

5.4.3 Launching keys

To launch FaceStream with Configurator, the keys are set using environment variables:

--env= - this parameter sets the environment variables required to start the container. The following basic values are specified:

- CONFIGURATOR_HOST=127.0.0.1 - host on which the Configurator service is running. The local host is set if the container is running on the same server where the Configurator is running.
- CONFIGURATOR_PORT=5070 - listening port for the Configurator service. By default, port 5070 is used.
- PORT=34569 - port where FaceStream will listen.
- STREAMS_ID="" - tag specifies a list of stream IDs that will be requested from LUNA Streams for processing. Other streams will be filtered. The "stream_id" parameter is given in response to the "create stream" request.

If the value is "" or the STREAMS_ID tag is not set, then FaceStream will take all existing "stream_id" from the queue.

If a non-existent value is set, an error about an incorrect UUID will be indicated when launching FaceStream.

By default, the value equals "".

To use the key, the CONFIGURATOR_HOST and CONFIGURATOR_PORT variables should be specified.

- STREAMS_NAME="" - list of streams names sets in this tag. Streams names are set using the "name" parameter at the time of their creation ("create streams" request). Streams with these names will be requested from LUNA Streams for processing. Other streams will be filtered.

Otherwise, the principle of operation is similar to the "STREAMS_ID" tag.

- GROUPS_ID="" and GROUPS_NAME="" - tags specify a list of group IDs or a list of group names. The parameters "group_id" or "group_name" are set during stream creation ("create stream" request). Streams with these parameters will be requested from LUNA Streams for processing. Other streams will be filtered.

If the value is "" or the GROUPS_ID/GROUPS_NAME tags are not set, then FaceStream will not filter streams by groups.

If a non-existent value is set, an error about an incorrect UUID will be indicated when launching FaceStream.

By default, the value equals "".

To use the keys, the CONFIGURATOR_HOST and CONFIGURATOR_PORT variables should be specified.

You can set multiple values for "STREAMS_NAME", "STREAMS_ID", "GROUPS_NAME" and "GROUPS_ID" tags. Syntax example: --env=STREAMS_ID="037f3196-c874-4eca-9d7c-91fd8dfc95934caf7cf7-dd0d-4ad5-a35e-b263e742e28a"

- CONFIGS_ID="" - tag is used to set a LUNA Configurator tag, which relates to the FaceStream main configurations. The same tag should be set for "TRACK_ENGINE_CONFIG" and "FACE_STREAM_CONFIG".

If the value is set to "" then the "TRACK_ENGINE_CONFIG" and "FACE_STREAM_CONFIG" records will be used by default. If the record by default does not exist or has an invalid JSON syntax, the configuration file from the distribution package will be used.

By default, the value equals "".

To use the key, the CONFIGURATOR_HOST and CONFIGURATOR_PORT variables should be specified.

- CONFIG_RELOAD = 1 - tag that enables checking for changes in the "FACE_STREAM_CONFIG" section of the LUNA Configurator service and takes the following values:
 - 1 - change tracking is enabled, if there are changes in the configuration, all FaceStream containers will be automatically restarted;
 - 0 - change tracking is disabled.

By default, the value equals 1.

- `PULLING_TIME = 10` - tag that sets the period for receiving new parameters from the “FACE_STREAM_CONFIG” section of the LUNA Configurator service in the range [1...3600] sec. Used in conjunction with the `CONFIG-RELOAD` tag.

By default, the value equals 10.

See how FaceStream works with LUNA Configurator in the section “Use FaceStream with LUNA Configurator” of the administrator manual.

5.4.4 Description of container launch parameters

`docker run` - command to launch the selected image as a new container.

`-v` - enables you to load the contents of the server folder into the volume of the container. This way the content is synchronized.

`-v /var/lib/fs/fs-current/extras/conf/configs/faceengine.conf:/srv/facestream/data/faceengine.conf \` - this parameter enables you to use the FaceEngine settings from the configuration file “faceengine.conf”.

`--network=host` - this parameter specifies that there is no network simulation and a server network is used. If you need to change the port for third-party containers, replace this line with `-p 5440:5432`. Here, the first port 5440 is the local port, and 5432 is the port used in the container.

`/etc/localtime:/etc/localtime:ro` - sets the current time zone used by the container system.

`--name=facestream` - this parameter specifies the name of the container to be launched. The name must be unique. If a container with the same name already exists, an error will occur.

`--restart=always` - this parameter defines the restart policy. Daemon always restarts the container regardless of the completion code.

`--detach=true` - running the container in the background.

6 Docker commands

6.1 Show containers

To show the list of launched Docker containers use the command:

```
docker ps
```

To show all the existing Docker containers use the command:

```
docker ps -a
```

6.2 Copy files to container

You can transfer files into the container. Use the `docker cp` command to copy a file into the container.

```
docker cp <file_location> <container_name>:<folder_inside_container>
```

6.3 Enter container

You can enter individual containers using the following command:

```
docker exec -it <container_name> bash
```

To exit the container, use the command:

```
exit
```

6.4 Images names

You can see all the names of the images using the command

```
docker images
```

6.5 Show container logs

You can view the container logs with the following command:

```
docker logs <container_name>
```

6.6 Delete image

If you need to delete an image:

- run the `docker images` command
- find the required image, for example: `dockerhub.visionlabs.ru/luna/v.5.1.10`
- copy the corresponding image ID from the IMAGE ID, for example, "61860d036d8c"
- specify it in the deletion command:

```
docker rmi -f 61860d036d8c
```

Delete all the existing images:

```
docker rmi -f $(docker images -q)
```

6.7 Stop container

You can stop the container using the command:

```
docker stop <container_name>
```

Stop all the containers:

```
docker stop $(docker ps -a -q)
```

6.8 Delete container

If you need to delete a container:

- run the `docker ps` command
- stop the container (see [Stop container](#))
- find the required image, for example: `dockerhub.visionlabs.ru/luna/v.5.1.10`
- copy the corresponding container ID from the CONTAINER ID column, for example, "23f555be8f3a"
- specify it in the deletion command:

```
docker container rm -f 23f555be8f3a
```

Delete all the containers:

```
docker container rm -f $(docker container ls -aq)
```